

# MediaPOS 80

## *Quick Start Guide*



Thanks for purchasing POS System MediaPOS 80.

In this manual you will find the most detailed functions & operations.

## **Checklist**


After opening the package, please check if the following content is included. If the item is incomplete or damaged, please contact the distributor.




MediaPOS 80



Thermal printing paper




Power cord




Adapter

## **Outward Diagram** **Front view**



DESCRIPTION	
1	Main display
2	Printer
3	Paper feed button
4	Printer open button


### **Side view**



DESCRIPTION
-------------


5	Camera position (optional)
6	Card reader position (optional)
7	Power Button

**Back View**



DESCRIPTION	
8	Secondary screen
9	Cable cover


**Android IO Ports**



DESCRIPTION	
10	USB port
11	Network port

12	HDMI port
13	OTG port
14	Earphone Port

### **X86 IO Ports**



DESCRIPTION	
15	USB port
16	Network port
17	COM port
18	VGA port

### **Starting up**

Press the power key to turn on.

### **Fast assembly**

1. Take down the cable cover and connect the adapter. As belows:



2. Take out the receipt printing paper from the packing carton, press the printer open button, and put the paper as below instruction:

